



MyDisc Quick User's Guide - Xpress


- Make sure CD-Remote is running (with or without 'ImageMaker EZ').
- Double-click on (Local) MyDisc.




1 Select 'Data disc from files' or 'Audio disc'.




2 Select the files you would like to copy from the top half of the window and drag them to the bottom panes.



3 Create your layout or open an existing layout.



4 Type in the Disc Name (volume ID) and number of discs you want to make. Click 'Make Disc' button.



5 Confirm the job summary and then submit by pressing the 'OK' button.